


35 | 50

GRAVITY



HOPETECH.COM

CAUTION: READ THIS BEFORE INSTALLING YOUR STEM!

Riding bicycles can be dangerous. These instructions should be read thoroughly before installation. Failure to follow these instructions before installing and using Hope Technology components can result in severe injury or death.

BOX CONTENTS

- Stem • 6 x Bolts

TOOLS REQUIRED

- 5mm Hex • Torque Wrench

PRODUCT SPECIFICATIONS

Depending on Stem model:

- Handlebar clamp diameter: $\varnothing 31.8\text{mm} - \varnothing 35\text{mm}$
- Length: 35mm - 50mm
- Rise: 0°
- Fork steerer tube: $\varnothing 1\frac{1}{8}"$ ($\varnothing 28.6\text{mm}$) **ONLY**

HOPE WARRANTY

All Hope Technology components are covered for two years from original date of purchase against manufacturer defects in material and workmanship. Proof of purchase is required. Product must be returned to the original retailer to process any warranty claim. This warranty does not cover any damage caused through mis-use or failing to comply by the recommendations given in this manual. This warranty does not affect your statutory rights.

PRELIMINARY CHECKS

001_Ensure that the steerer tube is cut cleanly and level and is free of any burrs (inside and outside). The stem should sit, once installed on the top of all headset parts and spacers, so that the steerer tube is approximately **2 to 3mm below** the top of the stem. This is equivalent to 37-38mm of clear space on the steerer tube above all headset parts and spacers **[See Fig A and B]**.

002_Ensure the steerer tube and handlebar clamp areas are both clean and dry **(NO GREASE!)**

003_It is also advisable to remove all bolts from the stem and apply a small amount of grease to the threads and under the bolt head. If you are fitting Ti bolts, it is preferable to use copper slip grease or Ti-Prep to avoid seizing.

Fig_A

